

Shavers

Type Number Model Number(s)

Micron Series

5422 eltron 900, 2101
5428 2005
5556 2505, 2515
5563 2501

Single Foil Series

5235 240 linear
5462 105 corded
5463 105, 100 entry
5464 209, 205 entry
5533 260, 270 linear
5596 259, 255 entry
5597 155, 150 entry

2000 series

5459 2060 entry
5461 2040, 2035 entry

3000 series

5419 3025 system 1-2-3
5424 3012 system 1-2-3
5469 3010 cord
5470 3550 universal
5564 3512 system 1-2-3
5567 3525 system 1-2-3
5569 3510 system 1-2-3
5579 action line system 1-2-3

4000 series

5403 4005 flex control corded
5471 4501 flex control
5501 4505 flex control
5502 4504 flex control
5580 4550 flex control
5584 4510 flex control
5584/28 4510 flex control
5585 4520 flex control
5585/09 4520 flex control
5586 4525 flex control

5000 series

5465	5315, 5316 flex integral
5466	5314 flex integral
5468	5505 flex integral
5476	5414 flex integral
5477	5415 flex integral
5478	5416 flex integral
5503	5525 flex integral
5504	5550 flex integral
5505	5515, 5520 flex integral
5506	5510 flex integral
5507	5015 flex integral

6000 series

5703	6525 flex integral ultra
5704	6550 flex integral ultra
5705	6515, 6520 flex integral ultra

7000 series

5494	7505 Syncro
5493	7526 Syncro
5492	7546 Syncro
5491	7570 Syncro

Clean & Charge

5301	SCC1 Clean and Charge system
------	------------------------------

Interface Shavers

5629	3610, 3612, 3615
------	------------------

Pocket Shavers

5523	pocket battery
5524	pocket battery deluxe
5525	pocket battery deluxe traveler
5614	350 pocket twist
5615	375 pocket twist plus

Lady Shavers

5666	lady elegance 3
5567	lady elegance 2

Hair Removers - Silk Epil

5271	EE 10
5285	EE 1
5291	EE 10 , duo plus
5292	EE 30 , duo rechargeable
5296	EE 100 / ER 100
5303	EE 1070, 1170
5304	ER 1270, 1373
5305	EE 1570, 1670
5306	ER 220

Beard Trimmers

5280	exact universal
5281	exact 6 memory universal
5601	EP 100, 80, 60

Shaver Model - to - Type Cross-Reference

10/00

Model Number	Type Number
105 corded	5462
105, 100 entry	5463
155, 150 entry	5597
2005	5428
2040, 2035 entry	5461
2060 entry	5459
209, 205 entry	5464
240 linear	5235
2501	5563
2505, 2515	5556
259, 255 entry	5596
260, 270 linear	5533
350 pocket twist	5614
375 pocket twist plus	5615
3010 cord	5469
3012 system 1-2-3	5424
3025 system 1-2-3	5419
3510 system 1-2-3	5569
3512 system 1-2-3	5564
3525 system 1-2-3	5567
3550 universal	5470
3610 interface	5629
3612 interface	5629
3615 interface	5629
4005 flex control corded	5403
4501 flex control	5471
4504 flex control	5502
4505 flex control	5501
4510 flex control	5584
4510 flex control	5584/28
4520 flex control	5585
4520 flex control	5585/09
4525 flex control	5586
4550 flex control	5580
5005 flex integral cord	5468
5015 flex integral	5507
5314 flex integral	5466
5315 flex integral	5465
5316 flex integral	5465
5414 flex integral	5476
5415 flex integral	5477
5416 flex integral	5478
5510 flex integral	5506
5515 flex integral	5505
5520 flex integral	5505
5525 flex integral	5503
5550 flex integral	5504
6515 flex integral ultra	5705

6520 flex integral ultra	5705
6525 flex integral ultra	5703
6550 flex integral ultra	5704
7505 Syncro	5494
7526 Syncro	5493
7546 Syncro	5492
7570 Syncro	5491
action line system 1-2-3	5579
EE 1	5285
EE 10	5271
EE 10 , duo plus	5291
EE 100 / ER 100	5296
EE 30 , duo rechargeable	5292
EE 1070	5303
EE 1170	5303
EE 1570	5305
EE 1670	5305
eltron 900, 2101	5422
EP 60	5601
EP 80	5601
EP 100	5601
ER 220	5306
ER 1270	5304
ER 1373	5304
exact 6 memory universal	5281
exact universal	5280
lady elegance 2	5667
lady elegance 3	5666
pocket battery	5523
pocket battery deluxe	5524
pocket battery deluxe traveler	5525
SCC1 Clean & Charge system	5301